



Hilltop
Over 40 Years' Experience

steinel

DE

GB

FR

NL

IT

ES

PT

SE

DK

FI

NO

GR

TR

HU

CZ

SK

PL

RO

SI

HR

EE

LT

LV

RU

BG



CN



MobileGlue 1007
MobileGlue 1007-S

Hilltop Products Ltd - www.hilltop-products.co.uk - Tel +4401942 723 101 - Email: sales@hilltop-products.co.uk

MobileGlue 1007/1007-S



GB Operating instructions

Please familiarise yourself with these operating instructions before using this product because prolonged reliable and trouble-free operation will only be ensured if it is handled properly. We hope your MobileGlue 1007/1007-S. brings you lasting satisfaction.

About this document

Please read carefully and keep in a safe place.

- Under copyright. Reproduction either in whole or in part only with our consent.
- Subject to change in the interest of technical progress.



Safety precautions

Before use


- Check the tool for any damage (Charging cable, housing etc.) before putting it into operation and do not use the tool if it is damaged.
- Do not use liquid or pasty adhesives!
- The glue reaches temperatures of up to 190 °C!



You could burn yourself!

After skin contact with hot glue: immediately cool with cold water. Do not try to remove hot-melt glue from the skin. If necessary, seek medical attention. After eye contact with hot-melt glue:

immediately cool for approx. 15 min. with running water and consult a doctor straight away.

- Use the applicator in dry rooms only.
- Do not use in conjunction with highly inflammable/combustible materials.
- Due to risk of fire, do not use on highly combustible surfaces or in combustible environments (e.g. paper, textiles etc.).
- The area you are glueing must be free of grease, dry and absolutely clean.
- Glue marks on clothing cannot be removed.
- Make sure heat-sensitive materials are suitable for glueing with hot-melt adhesive.
- Drips of glue are best removed when cold.
-  Do not pull the glue stick out of the applicator. Hot glue running into the applicator may cause damage.
- Do not leave the applicator unattended.
- This tool may be used by children aged 8 or above and by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they are supervised or have been given instructions on how to use the tool safely and under-

stand the hazards involved. Do not allow children to play with the tool. Children are not allowed to clean or carry out maintenance work on the applicator without supervision.

- Proper operation is only guaranteed by using genuine STEINEL sticks.

USB charging cable

- Keep the charging cable clean. Soiling may present the risk of an electric shock.
- Charge the applicator at a temperature ranging from 0 °C to 35 °C.
- Only charge the unit with the USB charging cable supplied with it (type 15.3841). Do not charge rechargeable batteries of other brands. They could catch fire or explode.

Rechargeable battery

- Do not open the applicator or the rechargeable battery. This could cause a short circuit. The rechargeable battery must not be removed. In the event of problems, contact the retailer you purchased the applicator from.
- The lithium-ion rechargeable battery can be recharged at any time without shortening its lifespan. Interrupting the charge cycle will not damage the rechargeable battery.

- When taking out of use for a long time, put the applicator away with battery charged. This will prolong the life of the lithium-ion rechargeable battery.
- Vapours may escape if the rechargeable battery is used improperly or damaged. Seek medical attention if you feel unwell and provide fresh air. The vapours may cause respiratory irritation.

Proper use

This electric tool is only intended for solvent-free glueing of handicraft materials and model components at home.

Application

Cordless hot-melt glue pen with rechargeable lithium-ion battery. The ideal all-purpose glue applicator for craft, decorating and making repairs. Suitable for: paper, card, cork, wood, leather, textiles, plastic, ceramics, foam, tiles etc.

System components

- ① USB charging cable
- ② LED display
- ③ Socket for charging cable
- ④ ON/OFF button
- ⑤ Feed trigger
- ⑥ Glue stick

Operating principle and handling

- Before using for the first time, fully charge the battery (2-3 hours) so as to prolong its life. (see Charging/ Operation)
- Insert glue stick into rear heating duct.
- When using the tool for the first time, press the trigger several times to fill the heating chamber with adhesive. It may also be necessary to give the glue stick a short push to help it move in.
- To prevent the applicator from being switched ON unintentionally, **you must press the button for approx. 2 sec.** Green LED flashes for 15 sec.
- Press trigger and apply glue to one side.
- Firmly press together the materials being glued, correcting alignment if necessary.
- Final bonding strength is reached after a very short time (approx. 2 minutes)!
- Spot glueing is recommended on long items with large surfaces.
- Rigid foam (e.g. polystyrene) can also be glued without a problem. Merely remember to apply the hot glue on the base surface and not on the polystyrene.

- When glueing textiles or similar materials, it is recommended to apply the hot glue in "wavy" lines.
- Let the applicator cool down after use.

Charging / Operation

The rechargeable battery in the MobileGlue 1007/1007-S comes partially charged. Before using the applicator for the first time, fully charge the battery (approx. 2-3 hours) to ensure full capacity.

The MobileGlue 1007/1007-S cannot be used while it is charging.

Interrupting the charge cycle will not damage the rechargeable battery. The battery can be recharged at any time without shortening its lifespan.

"Electronic Cell Protection (ECP)" protects the battery from exhaustive discharge. If the battery runs flat, protective circuitry switches the MobileGlue 1007/1007-S OFF and glue is no longer heated.

Charging with USB charger

Button	LED red	LED green	
ON/ OFF	●	○	Battery charging Applicator ready for use for a limited period
	○	●	Battery is fully charged, charge cycle is completed

Operation / glueing

GB

Button	LED red	LED green	
ON	○	☀	Switch ON. Press button for approx. 2 sec. Green LED flashes for 15 sec.
	○	●	Applicator ready for use Applicator starts for a further 5 min. each time you press the trigger
	○	○	No glueing for 5 min. Applicator switches OFF Switch applicator back ON at button
	☀	☀	Red and green LED flashes alternately after applicator has been in use for approx. 20 min. The applicator can now only be used for approx. another 10 min.
	☀	○	Red LED flashes 1× Battery flat, start charging using USB charger

Technical Specifications

Dimensions (H × B × T):	MobileGlue 1007 157 × 47 × 158 mm	MobileGlue 1007-S 179 × 40 × 65 mm
Battery:	lithium-ion	
Battery voltage, capacity:	3.6 V, 1.5 Ah	
Rechargeable-battery run time:	approx. 30 minutes (continuous operation)	
Battery charging time:	90% in 3 hours	
Warm-up time:	less than 15 seconds	
Melt temperature:	approx. 170°C	
Recommended glue sticks:	Ø 7 mm genuine STEINEL / Cristal sticks, Prod. No. 006594, 006624 / Ultrapower sticks, Prod. No. 006730, 006747 / Color sticks, Prod. No. 006969 / Glitter sticks, Prod. No. 065539	

Disposal

Electrical and electronic equipment, accessories and packaging must be recycled in an environmentally compatible manner.

EU countries only:

Under the current European Directive on Waste Electrical and Electronic Equipment and its implementation in national law, electrical and electronic equipment no longer suitable for use must be collected separately and recycled in an environmentally compatible manner.



Do not dispose of electrical and electronic equipment as domestic waste.



Do not throw devices, rechargeable batteries/batteries into household waste, fire or water at the end of their useful life.

Rechargeable batteries/batteries should be collected, recycled or disposed of in an environmentally friendly manner.

EU countries only:

In accordance with Directive 2006/66/EC, defective or spent rechargeable batteries/batteries must be recycled. Waste rechargeable batteries/batteries can be returned to the point of purchase or to a collection facility for hazardous substances.

Manufacturer's warranty

Manufacturer's warranty of STEINEL GmbH, Dieselstrasse 80-84, 33442 Herzebrock-Clarholz, Germany

All STEINEL products meet the highest quality standards. For this reason, we, the manufacturer, are pleased to provide you, the consumer, with a warranty under the following terms and conditions:

The warranty covers the absence of deficiencies which are proven to be the result of a material defect or fault in manufacturing and which are reported to us immediately after detection and within the warranty period.

The warranty shall apply to all STEINEL products sold and used in Germany - excluding STEINEL Professional products.

You can opt for warranty cover in the form of repair or replacement which will be provided free of charge (if applicable, in the form of a successor model of the same or higher quality) or in the form of a credit note.

The warranty period for the STEINEL product you have purchased is **3 years** in each case from the date on which the product was purchased.

We shall bear the shipping costs but not the transport risks involved in return shipment.

Statutory rights accruing from defects, gratuitousness

The warranty cover described here shall be

applicable in addition to the statutory rights of warranty – including special consumer protection provisions – and shall not restrict or replace them. Exercising your statutory rights in the event of defects is gratuitous.

Exemptions from the warranty

All replaceable lamps are expressly excluded from this warranty. In addition to this, the warranty shall not cover:

- any wear resulting from use or any other natural wear of product parts or any deficiencies in the STEINEL product that are attributable to wear caused by use or other natural wear,
- any improper or non-intended use of the product or any failure to observe the operating instructions,
- any unauthorised additions, alterations or other modifications to the product or any deficiencies attributable to the use of accessory,
- supplementary or replacement parts which are not genuine STEINEL parts,
- any maintenance or care of products that is not carried out in accordance with the operating instructions,
- any attachment or installation that is not in accordance with STEINEL's installation instructions,
- any damage or loss occurring in transit.

Application of German law

The warranty shall be governed by German law excluding the United Nations Convention concerning the International Sale of Goods (CISG).

Making claims

If you wish to make a warranty claim, please send your product complete and carriage paid with the original receipt of purchase, which must show the date of purchase and product designation, either to your retailer or directly to us at STEINEL (UK) Ltd. – 25 Manasty Road, Axis Park, Orton Southgate, GB- Peterborough Cambs PE2 6UP United Kingdom. For this reason, we recommend that you keep your receipt of purchase in a safe place until the warranty period expires.

3 YEAR
MANUFACTURER'S
WARRANTY

